

1 Mirror your image or artwork

2 Run a few sheets of blank paper through the printer to warm it up to operating temperature. Select normal print quality and gradually increase the paper weight setting until the toner fuses well and the image does not smudge*. Print on the blank side of the transfer paper, one sheet at a time using a bypass tray if possible

*You may have to use a slow paper setting e.g. heavy paper, transparency or label mode. If in doubt, consult your printer manufacturer.

Print on the blank/unprinted side of the transfer paper

3 Trim around or contour cut the image
Note: This paper has a clear film background

SILHOUETTE BLADE SETTING*

SPEED 3 THICKNESS 2

*Adjust as necessary. Use a cutting mat (carrier sheet) and cut through the film layer only

4 Prepare the heat press at **190°C / 375°F***

*Difficulty peeling indicates not enough heat

5 Place image face down on substrate

6 Apply **medium to heavy** pressure for **26 seconds**

7

Peel whilst hot

24hrs before washing

yolo tip

Repressing for 5-7 seconds with a Teflon or silicone sheet and lightly stretching the transfer when warm will increase softness and durability

wash and care instructions

leave 24hrs

Machine wash separately

Dry at low heat setting

Do not dry clean, bleach or directly iron transfer

contact

hello@yolo.co.uk

+44 (0) 2082 400 658

www.yolo.co.uk

Product code: **TPEZ**

Store in a cool, dry place and seal the packaging between uses

Printed on 100% recycled paper