


1

Mirror your image or artwork



2

Cut your image using a contour/plotter cutter, ensuring the blade cuts through the film only and not the release liner



**CRICUT GUIDELINES\***

SETTING **Glitter Iron On**  
BLADE **Standard Fine Cut**  
PRESSURE **Default/Added Pressure**


**SILHOUETTE**  
BLADE SETTING\* **3**

SPEED 5 FORCE 30

\*Adjust as necessary. Use a cutting mat (carrier sheet) and cut through the film layer only. Test cuts are recommended.

3

Weed away the unwanted film, leaving the image on the release liner (a weeding tool may help)




4

Prepare the heat press at **160°C / 320°F**




5

Place image face down on substrate




6

Cover with a Teflon or silicone sheet



7

Apply **medium to heavy** pressure for **10-15 seconds**



8



Peel when warm\*

24hrs before washing

\*After approximately 5 seconds

## wash and care instructions



Machine wash separately



Dry at low heat setting



Do not bleach or directly iron image

## contact

hello@yolo.co.uk

+44 (0) 2082 400 658

www.yolo.co.uk

Product code: **GLIT**

! Store your film in a cool, dry place and seal the packaging between uses