

1

Mirror your image
or artwork




2

Select normal print quality and a plain or photo paper setting.
Print on the blank side of the transfer paper, one sheet at a time



Print on the blank/unprinted
side of the transfer paper



3

Trim around or contour
cut the image
Note: This paper has a
clear film background




SILHOUETTE
BLADE SETTING* 
SPEED 3 THICKNESS 1

*Adjust as necessary. Use a cutting mat (carrier sheet)
and cut through the film layer only

4

Pre-heat iron for **3 minutes** on the highest cotton setting




5

Choose a smooth hard
surface at waist level



6

Place image face down on substrate
Using two hands slide the iron vertically up and down




The iron should be
halfway off the edge of
the transfer when the
edges are ironed

In **90 seconds** the iron
should make two
passes over the surface
of the transfer

7

Using two hands firmly slide the iron horizontally side to side



The iron should be
halfway off the edge of
the transfer when the
edges are ironed

In **90 seconds** the iron
should make two
passes over the surface
of the transfer

8



24hrs
before
washing

1 Mirror your image or artwork

2 Select normal print quality and a plain or photo paper setting. Print on the blank side of the transfer paper, one sheet at a time

Print on the blank/unprinted side of the transfer paper

3 Trim around or contour cut the image
Note: This paper has a clear film background

SILHOUETTE BLADE SETTING*
SPEED 3 THICKNESS 1

*Adjust as necessary. Use a cutting mat (carrier sheet) and cut through the film layer only

4 Prepare the heat press at **190°C / 375°F**
*Reduce to 175°C/350°F if necessary

5 Place image face down on substrate

6 Apply **heavy** pressure for **30 seconds**
*Reduce to 20 seconds if necessary

7

Peel whilst hot*
*Peel cold for a shinier finish

24hrs before washing

yolo tip
Repressing for 5-7 seconds with a Teflon or silicone sheet (remove when cold) and lightly stretching the transfer when warm will increase softness and durability

Note: This paper requires heavy pressure and a high temperature to transfer successfully. Hand-ironing may be possible but is not recommended

wash and care instructions

leave 24hrs
Machine wash separately
Dry at low heat setting
Do not dry clean, bleach or directly iron transfer

contact

hello@yolo.co.uk
+44 (0) 2082 400 658
www.yolo.co.uk

Product code: JPSS

! Store in a cool, dry place and seal the packaging between uses

Printed on 100% recycled paper