

1

Prepare your image
or artwork




2

Select high print quality and a photo paper setting



Print on the slightly textured
side of the film



3

Leave the image for
approximately **30 minutes**
to allow the ink to dry



4

Trim around or contour
cut the image
Note: This film has a
white background



**SILHOUETTE
BLADE SETTING*** 
SPEED 5 THICKNESS 10

*Adjust as necessary. Use a cutting mat (carrier sheet)
and cut through the film layer only

5




Peel off backing paper



6

Position the image facing upwards on the chosen surface*



-  Smooth
-  Clean
-  Dry

*Adheres to most clean surfaces and can be removed and repositioned but adhesive will become less effective as it collects dust, dirt or fibres

7

Avoid fingerprints or
getting the film wet



*Pigment inks are recommended
for greatest water resistance

care instructions



Avoid
moisture



Avoid
fingerprints




Avoid
direct sunlight

contact

 hello@yolo.co.uk

 +44 (0) 2082 400 658

 www.yolo.co.uk

Product code: **PTEX**



Store in a cool, dry place and seal the packaging between uses

 Printed on 100% recycled paper