

1 Mirror your image or artwork

2 Run a few sheets of blank paper through the printer to warm it up to operating temperature. Select normal print quality and gradually increase the paper weight setting until the toner fuses well and the image does not smudge*. Print on the blank side of the transfer paper, one sheet at a time using a bypass tray if possible

*You may have to use a slow paper setting e.g. heavy paper, transparency or label mode. If in doubt, consult your printer manufacturer.

Print on the blank/unprinted side of the imaging paper

3 Trim away excess transfer areas but leave a border around the image

4 Position the image face down on substrate, securing with thermal tape if necessary

5 Prepare the heat press at **165°C / 325°F**

6 Apply medium to heavy pressure for the time recommended below*:

Mugs & Glass/ Steins		Metal & Wood	
Photo Slate		Ceramic Tiles	

*If there is a faint residue around the image, try decreasing the pressure and/or time. If toner is discoloured/mottled, use a heating pad to slow the transfer of heat. If areas of light toner do not transfer, try increasing the pressing time.

7 Run under cold water* to cool item before removing the backing paper

Peel when cold

*Cool glass items in a fridge to prevent cracking

8

24hrs before washing*

*Minimal handling and washing will reduce the changes of scratching/chipping

wash and care instructions

Hand wash

! Store in a cool, dry place and seal the packaging between uses

contact

hello@yolo.co.uk

+44 (0) 2082 400 658

www.yolo.co.uk

Product code: **TPHS**

Printed on 100% recycled paper